

Underground tanks, gas odors, asbestos, or other unanticipated evidence of suspected contamination encountered.

NOTE: This process is NOT for use for spills caused by the construction contractor or the motoring public.

IMMEDIATELY STOP WORK in the vicinity of the find(s). Evacuate and cordon off the area(s) of concern. Do not allow construction personnel to do any exploratory or investigative work that could result in further personal exposure. Contact District Hazardous Waste Technical Specialist (DHWTS) and Environmental Construction Liaison (ECL) to assist and to perform field review if appropriate.

In coordination with the DHWTS and the ECL, access the District Construction Emergency Response Contract. Also contact and consult with the District Hazardous Waste Material Coordinator, Maintenance Hazardous Spill Coordinator, and the District Proposition 65 Coordinator, as appropriate. Document actions and results.

